


SELECTING HOSE SIZE BY FLOW CAPACITY

HOW TO USE THIS CHART: Determine the proper flow rate your system requires, then connect a straight edge from the selected flow rate to the recommended velocity range. The required hose I.D. will appear at the intersection of the straight edge and the center column. If the straight edge passes through the scale between sizes listed, use the next larger I.D. Hose.

EXAMPLE (highlight below in chart): The flow rate your system requires is 10 gallons per minute. Connect your straight edge from the 10 gallon per minute flow rate column to the recommended velocity range for pressure lines of 10 feet per second (fps). The straight edge intersects at 5/8", so the recommended hose I.D. is 5/8".

Disclaimer: The only way to get a true reading is by the use of a flow meter.



Because we continually examine ways to improve our products, we reserve the right to alter specifications or discontinue products without prior notice.